

## **User Manual:**

### **YODIN-XXI Antibacterial Knife Sheath**

Thank you for choosing YODIN-XXI Antibacterial Knife Sheath. This user manual is designed to provide you with comprehensive instructions on how to properly use and maintain the product.

#### **PADS - XXI**

1. Preparing the pads
  - Drop the pads on a hard surface in the correct orientation, so that its contents are in the right place before cutting them open as shown on the packaging.
  - Cut open the pads and remove the small piece you have cut off.
  - **Make sure the plastic sheets inside is folded in each direction to guide the knife in to the pads.**
2. Inserting the pads
  - Remove the lid and wiper from the YODIN-XXI Antibacterial Knife Sheath.
  - Hold the sheath straight with the opening pointing up and insert the pads.
  - Fold the “wings” of the pads to each side, one towards the front and one towards the back.
  - Ensure that the edges of the opening of the pads and the top of the pads are flush with the Antibacterial knife sheath's opening.
  - Verify that the plastic inside of the Antibacterial knife sheath is pointing in the correct direction before placing the wiper on top.
  - Ensure that the wiper fits the pattern and is correctly placed.
3. Sealing the Antibacterial knife sheath
  - Place the wiper correctly on top of the knife sheath.
  - Insert the lid into the guides on the edges of the sheath.
  - Push the lid down with a firm grip until you hear a solid "click" indicating that the lid is in the correct position.

Note: Use a new PADS - XXI for each new shift.

#### **YGDR Tool belt and Neck belt**

To ensure proper use and maintenance of your belt, please follow the instructions below:

1. Open the packaging and unroll the length of the belt.
2. Try the belt around your waist to see if it fits. If you need to adjust the size, place the belt on a clean, flat surface and loosen the screws on one side. Adjust the belt equally on both sides if you need to adjust it by more than one hole.
3. Slide the belt transfer onto the correct side of the belt. If you are right-handed, place the belt transfer on the right side, and keep the side of the belt with two push-on buttons on the left side. If you are left-handed, slide the belt transfer onto your left side, keeping the two push-on buttons on the right side.

4. If you need to add an extra hole to the belt, use a machine that is designed for this purpose. If you need additional length, we recommend adding a chain to the rear belt mount.
5. Always click the belt on your back (behind) and ensure that the belt rests firmly on your hips. Do not allow the belt to hang or sag.
6. Do not wash your leather belt in a washing machine. If necessary, wipe it down with a damp cloth.
7. Once a year (or as needed), treat your leather belt with leather wax. Rub the wax in thoroughly and wipe with a dry cloth.

By following these guidelines, you can ensure that your belt remains in good condition and provides optimal performance.

### **How to Add YNIVA Apron and Cloth**

Congratulations on choosing the YGDRA Toolbelt for your work needs. To ensure maximum functionality and comfort, it is essential to properly adjust the toolbelt to fit your body before attaching the YNIVA Apron and Cloth.

Once you have adjusted your YGDRA Toolbelt, follow the steps below to attach the YNIVA Apron and Cloth:

#### **Step 1: Click-on the YNIVA Apron**

The YNIVA Apron can be easily attached to the YGDRA Toolbelt using the buttons on the sides. Locate the one button on one side and one of the two buttons on the other side of the apron.

Align the buttons with the corresponding slots on the toolbelt and click-on the apron. Ensure that the apron is securely attached to the toolbelt.

#### **Step 2: Use the Other Button for the YNIVA Snap-on Cloth**

The YNIVA Snap-on Cloth can also be attached to the YGDRA Toolbelt using the buttons on the sides. Locate the other button on the side of the apron and align it with the slot on the toolbelt.

Make sure to use the button placed towards the back for the YNIVA Snap-on Cloth. This will ensure that the cloth is securely attached to the toolbelt and will not interfere with your work.

#### **Step 3: Wash Before Use**

We recommend washing your YNIVA Apron and Cloth before use. This will help remove any excess dyes or chemicals used during the manufacturing process and make it easier to clean difficult stains later on.

#### **Step 4: Follow Care-Tag Instructions**

When washing your YNIVA Apron and Cloth, refer to the care-tag for specific washing instructions. These instructions will ensure that the fabric remains in good condition and does not shrink or fade.

By following these simple steps, you can easily attach the YNIVA Apron and Cloth to your YGDRA Toolbelt and ensure maximum functionality and comfort while you work.

### **How to Add the Antibacterial Knife Sheath on the Belt:**

In addition to the YNIVA Apron and Cloth, the YGDRA Toolbelt also comes with the YODIN - XXI Antibacterial knife sheath, which can be easily attached to the belt for convenient access to your knife while you work.

Follow the steps below to **attach the YODIN - XXI Antibacterial knife sheath on the belt:**

**Step 1: Fill the YODIN - XXI Antibacterial Knife Sheath with PADS - XXI**

Before attaching the YODIN - XXI Antibacterial knife sheath on the belt, make sure to fill it with a new and fresh PADS - XXI. This will ensure that your knife remains clean and bacteria-free while stored in the sheath.

**Step 2: Hold the YODIN - XXI Antibacterial Knife Sheath in your Right Hand**

Hold the YODIN - XXI Antibacterial knife sheath in your right hand with the knife facing downwards.

**Step 3: Slide the Sheath onto the Belt Transfer**

Turn your head towards the belt transfer on your right (or left) side and gently slide the YODIN - XXI Antibacterial knife sheath onto the guides on the belt transfer. Keep sliding it down until you hear a solid "KLICK". This sound indicates that the sheath is securely attached to the belt transfer.

If you do not hear a solid "KLICK", try again by adjusting the position of the sheath on the guides until it clicks into place.

**Step 4: Remove/Loosen the Sheath from the Belt Transfer**

To remove or loosen the YODIN - XXI Antibacterial knife sheath from the belt transfer, hold your left hand onto the BV logo sign on the top of the belt transfer, push it in, and then use your other hand to lift it up. This will release the sheath from the guides on the belt transfer, and you can easily remove it from the belt.

By following these simple steps, you can easily attach the YODIN - XXI Antibacterial knife sheath to the YGDRA Toolbelt and ensure easy access to your knife while you work.

**How to insert the knife with YODIN - XXI Antibacterial knife sheath:**

First, ensure that you have adjusted the belt to fit and have correctly placed the YODIN - XXI Antibacterial knife sheath. Next, turn your head and position yourself correctly to where the knife is to be inserted. Always handle the knife with care and attention.

To insert the knife, start by placing the tip of the knife over the wiper on top of the sheath. Make sure the sharp edge is facing up, and the back of the knife is facing down and towards the wiper. Insert the knife gently, ensuring that it is straight and in the right position.

Repeat this exercise to ensure that the knife is properly inserted into the sheath. If you feel any resistance, remove the knife, take off the YODIN - XXI Antibacterial knife sheath, and check that the PADS - XXI is placed correctly inside. Once the pads are correctly positioned, reinstall the sheath and try again.

Please note that the wiper on top of the sheath can be turned around. If you experience minor injuries while using the knife, you can turn the wiper around to use the other side. However, for major injuries, you will need to replace the wiper.

**To remove the pads from the YODIN - XXI Antibacterial knife sheath, follow these steps:**

1. Loosen the YODIN - XXI Antibacterial knife sheath from the belt transfer after each shift.
2. Remove the lid and wiper from the sheath.
3. Take out the PADS - XXI from inside the sheath.

Dispose of the used PADS - XXI and any other associated waste in an approved waste disposal facility. The PADS - XXI are flammable, so ensure that you dispose of them in a manner that is compliant with all applicable regulations (HP 3 - flammable).

By following these steps, you can maintain the cleanliness and effectiveness of your YODIN - XXI Antibacterial knife sheath.

To ensure that your YODIN - XXI Antibacterial knife sheath remains in good condition and continues to provide reliable service, you should take care of it properly. Here are some care tips:

1. Rinse each part of the YODIN - XXI Antibacterial knife sheath in running water after each use.
2. If necessary, wash the parts with lukewarm water and rinse them with fresh water.
3. Allow the parts to dry in a clean place before storing them for the next use.
4. While all the parts can stand up to dishwasher washing, we do not recommend this type of washing. It may alter the color and cause twists in the sheath.
5. Do not leave your knife inside the YODIN - XXI Antibacterial knife sheath when it is not in use.

By following these care tips, you can help to extend the life of your YODIN - XXI Antibacterial knife sheath, keep it in good condition, and ensure that it continues to provide reliable service.

**When using the YODIN - XXI Antibacterial knife sheath, please keep in mind the following instructions:**

1. Keep the sheath away from flames and hot surfaces. Do not expose it to ignition sources.
2. Use the sheath only for its intended purpose, which is to protect your knife while not in use.
3. Always handle your knife with care, following appropriate safety procedures.

Additionally, the steel slides on the sides of the sheath can be engraved with your name or your restaurant's name for personalization and identification purposes. This customization option is a great way to add a personal touch to your knife sheath.

By following these instructions, you can safely and effectively use the YODIN - XXI Antibacterial knife sheath for all of your food preparation needs.

To ensure the safety and effectiveness of the YODIN - XXI Antibacterial knife sheath, please follow these guidelines:

**Do's:**

1. Always use the PADS - XXI for a maximum of 12-hour shifts.
2. Ensure that the PADS - XXI is whole, wet, and has no holes before use.
3. Always ensure that the knife is visibly clean and dry before inserting it in the YODIN - XXI Antibacterial knife sheath. !When handling ingredients containing allergens, always make sure that the knife is properly cleaned before inserting it into your Antibacterial knife sheath, in order to avoid allergen transfer!

**Don'ts:**

1. Do not use the PADS - XXI for more than 12-hour shifts.
2. Do not use the PADS - XXI if it is damaged or has holes.
3. Do not insert a dirty or wet knife in the YODIN - XXI Antibacterial knife sheath.
4. Do not use the YODIN - XXI Antibacterial knife sheath for any other purpose than intended.

By following these guidelines, you can maintain the effectiveness and safety of the YODIN - XXI Antibacterial knife sheath and ensure that it continues to perform at its best.

**Additional information:**

PADS - XXI Interchangeable antibacterial and disinfective pads for YODIN - XXI Antibacterial knife sheath.

- Fits most knives with 21 cm long blade or shorter.
- Ethanol (60-80%), purified water, PP (virgin ) and absorbent (viscose and polyester), aluminum/paper/plastic wrapping.
- PADS - XXI Interchangeable pads for disinfection of knife blades or other equipment.
- New and innovative biocide solution with documented effect on stopping bacterial growth and spread.
- Product: Use the product as intended. User manual: [www.bonvivant.no/usermanual](http://www.bonvivant.no/usermanual)
- Do not use directly on hands or skin, and do not consume!
- Cut the pads on top, fold the bottom and insert the pads to YODIN - XXI.
- Insert your knife dry and clean.
- The active fluids will keep the blade disinfected.
- Leave the blade in for > 15 seconds.
- Let the blade air dry before use.
- Active substance: Ethanol 590 g/l 75% Ethanol, 25% purified water.
- Disinfectants for areas that come into contact with food and feed.
- Produced by: Walright Group Suzhou Company Jiangsu Sunclean Medical Co.,Ltd. China
- For: Bon Vivant AS Norway [www.bonvivant.no](http://www.bonvivant.no)
- DANGER Highly flammable liquid and vapour.

- Keep away from heat, hot surfaces, sparks, open flames, and other ignition sources. No smoking.
- Keep container tightly closed. In case of fire: use water mist/carbon dioxide/alcohol-resistant foam to extinguish.
- Store in a well-ventilated place. Keep cool.
- Dispose of contents/container to an approved waste disposal plant (HP 3 - flammable).
- Do not ingest!
- If in contact with eyes/soft parts: rinse with water and contact doctor if necessary.
- Keep away from children.
- Series: SC/AF004446/22
- Production date: 2023-3-31
- Durable: 5 years

We hope this manual has been helpful in guiding you on how to use the YODIN - XXI Antibacterial Knife Sheath PADS - XXI Interchangeable disinfective and Antibacterial pads, YGDRA Tool belt and Neck belt and YNIVA Snap-on Apron and Cloth correctly. If you have any questions or concerns, please contact our *customer service team*